

Wiring in multiple WS-600 sensors to the WA-700 or HS-700

1. Wiring 2 sensors into the WA-700 or HS-700

First, remove black plug (pictured at right) from the WA-700 or HS-700.

Second, remove black plug from second sensor by loosening the screws that hold the wire in the black plug.

Third, loosen screws on black plug of original sensor and insert wires from the 2nd sensor into the same holes as the original sensor.

Finally, install black plug back into the WA-700 or HS-700. Wiring should look like below image.



2. Wiring 3 or more sensors into the WA-700 or HS-700

First, remove black plug (pictured at right) from the WA-700 or HS-700.

Second, remove black plug from additional sensors by loosening the screws that hold the wire in the black plug.

Third, add 3-4 inch length of wire from original plug. (Exactly like image to the right).

Fourth, twist the wires from the additional sensors together as shown below.



Fifth, now twist those wires to the 3-4 inch length from the original plug as shown below. These can be held together by a wire nut or covered in black electrical tape. (Below is example of how this should look before black tape or wire nut.)



Finally, install black plug back into the WA-700 or HS-700.