

PHONEALARM INSTRUCTIONS

General Information

The PhoneAlarm (Model TG-1100T-CONS-45F) automatically dials your preprogrammed telephone number and sounds an alarm tone when the temperature drops below 45°F ($\pm 7^\circ\text{F}$). The PhoneAlarm will continuously re-dial every 16 minutes until it is disabled or conditions are corrected.

Installation Instructions

1. Plug the PhoneAlarm cord into a direct phone outlet. Caution: PhoneAlarm will not work with PBX or other multiline systems.
 2. If you want your telephone to remain in use, plug the PhoneAlarm into a second phone outlet or use a dual plug adaptor (not included).
- IMPORTANT:** Do not set room thermostat lower than 55°F.

Operation

TO PROGRAM AND TEST: Decide which phone number you want the PhoneAlarm to call (your home, a neighbor's home, your office, a relative, etc.) when temperature drops below 45°F. Start the programming sequence by pressing the * (star) key for three seconds. Without releasing the * key, press the # (number) key. With both * and # keys depressed, simply enter the desired call-out number into the PhoneAlarm, including 1 and area code if needed (11 digit limit). The red indicator light will blink as the numbers are entered. (If the unit did not blink as you entered the numbers, carefully repeat the above procedure.) After the light stops blinking, continue holding the two keys down for another three seconds before releasing.

For actual testing with someone at each location, repeat the above sequence, but continue to press (hold) the # key while releasing only the * key. The party at the call-out location will now hear the alarm tone. After several seconds or upon release of the # key, the PhoneAlarm will automatically hang up. The test is now complete.

TO DISABLE: After receiving the alarm call, wait five minutes and dial the PhoneAlarm location's phone number (not the programmed number). The PhoneAlarm will answer after 16 rings and sound an alarm tone. This tone verifies the PhoneAlarm has been disabled and will not call out again while in current alarm situation. Once alarm conditions have been corrected, the PhoneAlarm will automatically reset to working status.

TO CHECK STATUS OF PHONEALARM FROM ANY LOCATION: Call the PhoneAlarm phone number. If the PhoneAlarm continues to ring beyond 16 rings, it is not in alarm. If you hear a busy signal, or after 16 rings you hear the disable alarm tone, the PhoneAlarm is in alarm.

BATTERY: Remove the four screws and back of PhoneAlarm case to install 9V battery (not included). The purpose of the battery is to store your preprogrammed number in memory in the event of phone power interruption. Failure to use a battery can result in phone number memory loss.

TELEPHONE ANSWERING MACHINES: When the Phone Alarm is in the alarm mode, it will dial the call-out number every 16 minutes until disabled. To avoid repeated long distance phone line service charges, we do not recommend the use of answering machines at the call-out number location.

2/10/92

TECH SUPPORT: 952-448-2217